

Florsheim
SHOE COMPANY



FALL 2024 CATALOG



NORWALK
Collection





FORGE
Collection



Renegade Plain Toe 4-Eye Boot

15212



010



215



221

010 Black CH | 215 Brown Crazy Horse | 221 Cognac

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14

Renegade Cap Toe Lace Up Boot

15211



221



010



215

221 Cognac | 010 Black Crazy Horse | 215 Brown Crazy Horse

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14

Renegade Wingtip Lace Up Boot

15202



215

215 Brown Crazy Horse

Smooth, casual leather upper, breathable jersey textile linings for additional comfort, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14

Renegade Plain Toe Chukka Boot

15199



215



001

215 Brown Crazy Horse | 001 Black

Smooth or casual leather upper, breathable jersey textile linings for additional comfort, fully cushioned, removeable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14

Renegade Plain Toe Gore Boot

15201



001



215

001 Black | 215 Brown Crazy Horse

Smooth or casual leather upper, breathable jersey textile linings for additional comfort, fully cushioned, removeable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14

Renegade Wingtip Oxford

15198



221



001

221 Cognac | 001 Black

Smooth leather upper, breathable jersey textile linings for additional comfort, fully cushioned, removeable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14

Renegade Plain Toe Oxford

15210



215



010

215 Brown Crazy Horse | 010 Black Crazy Horse

Casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14

Lodge Cap Toe Lace Up Boot

14286



215



010



205

215 Brown Crazy Horse | 010 Black Crazy Horse | 205 Chestnut

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14

Lodge Plain Toe Chukka Boot

14284



010



205



215

010 Black Crazy Horse | 205 Chestnut | 215 Brown Crazy Horse

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14

Lodge Plain Toe Gore Boot

14285



205



010



215

205 Chestnut | 010 Black Crazy Horse | 215 Brown Crazy Horse

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14

Forge Plain Toe Lace Up Boot

14432



221



001

221 Cognac | 001 Black

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable footbed with OrthoLite® high rebound foam for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Forge Plain Toe Gore Boot

14431



001



221

001 Black | 221 Cognac

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable footbed with OrthoLite® high rebound foam for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Forge Plain Toe Chukka Boot

14430



221



001

221 Cognac | 001 Black

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable footbed with OrthoLite® high rebound foam for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Norwalk Plain Toe Lace Up Boot | COMFORTECH

13376



215



006



222

215 Brown Crazy Horse | 006 Black Nubuck | 222 Cognac Milled

Casual leather or nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Norwalk Side Zip Boot | COMFORTECH

13393



010



215

010 Black Crazy Horse | 215 Brown Crazy Horse

Water-resisting casual leather or suede upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 8-11, 12, 13

Norwalk Plain Toe Chukka Boot | COMFORTECH

13370



010



215

010 Black Crazy Horse | 215 Brown Crazy Horse

Casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Norwalk Moc Toe Slip On | COMFORTECH

13404



001



221

001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for all-day comfort, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Norwalk Plain Toe Oxford | COMFORTECH

13369



229



009



010



200



215



222



249



410

229 Cognac Smooth | 009 Black Multi | 010 Black Crazy Horse | 200 Brown | 215 Brown Crazy Horse | 222 Cognac Milled | 249 Brown Crazy Horse | 410

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed for all-day comfort, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

(009, 200, 222, 410) M 7-12, 13, 14, 15, 16 W 7-11, 12, 13, 14

(010, 215, 229, 249) M 7-12, 13, 14, 15, 16 W 7-11, 12, 13, 14, 15

Norwalk Wingtip Oxford | COMFORTECH

13414



215



010



020



229

215 Brown Crazy Horse | 010 Black Crazy Horse | 020 Gray | 229 Cognac Smooth

Smooth leather, crazy horse leather, or milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14, W 7-11, 12, 13, 14

Norwalk Cap Toe Oxford | COMFORTECH

13368



222



010



215

222 Cognac Milled | 010 Black Crazy Horse | 215 Brown Crazy Horse

Casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed for all-day comfort, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14

Vibe Plain Toe Chukka Boot | COMFORTECH

14433



010



215

010 Black Crazy Horse | 215 Brown Crazy Horse

Casual leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with a rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Vibe Wingtip Oxford | COMFORTECH

14417



229



009



221

229 Cognac Smooth | 009 Black Smooth | 221 Cognac

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Vibe Plain Toe Oxford | COMFORTECH

14418



215



009



229

215 Brown Crazy Horse | 009 Black Smooth | 229 Cognac Smooth

Smooth or casual leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Vibe Knit Plain Toe Oxford | COMFORTECH

14420



410



001



020

410 Navy | 001 Black | 020 Gray

Knit textile with nubuck and smooth leather upper, unlined shoe, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Vibe Canvas Plain Toe Oxford | COMFORTECH

14419



020



001

400

020 Gray | 001 Black | 400 Blue

Canvas with smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Highland Plain Toe Oxford

14272



221

221 Cognac

Smooth leather upper, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for all-day comfort, durable and cushioned EVA outsole with rubber heel for abrasion resistance

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14

Highland Canvas Plain Toe Oxford

14273



410



001

020

410 Navy | 001 Black | 020 Gray

Canvas with leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for long-term wearability, durable and cushioned EVA outsole with rubber heel for abrasion resistance.

M 7-12, 13, 14

Satellite Knit Elastic Lace Slip On Sneaker | COMFORTECH 14422



020



001

108

410

020 Gray | 001 Black | 108 Ice | 410 Navy

Knit textile with nubuck upper, comfortable stretch textile linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, shock absorbing EVA midsole for utmost comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14

Satellite Perf Lace Up Sneaker | COMFORTECH 14423



221



001

410

221 Cognac | 001 Black | 410 Navy

Perfed smooth leather with mesh upper, comfortable stretch textile and mesh linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort shock absorbing EVA midsole for utmost comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14

Dash Wingtip Oxford | COMFORTECH 11768



111



229

111 Black | 229 Cognac Smooth

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Dash Plain Toe Oxford | COMFORTECH 11783



229



001

111

215

229 Cognac Smooth | 001 Black | 111 Black & White | 215 Brown Crazy Horse

Smooth leather or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Heist Lace to Toe Sneaker | COMFORTECH

14352



221



001



111

221 Cognac | 001 Black | 111 White

Leather or leather with suede upper, breathable mesh linings, fully cushioned, removable Comfortech footbed with OrthoLite® high rebound foam for long-term wearability, shock absorbing EVA midsole for utmost comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Heist Knit Lace to Toe Sneaker | COMFORTECH

14354



020



001



125



410

020 Gray | 001 Black | 125 Oyster | 410 Navy

Knit textile with smooth leather and suede upper, breathable mesh linings, fully cushioned, removable Comfortech footbed with OrthoLite® high rebound foam for long-term wearability, shock absorbing EVA midsole for utmost comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14

Social Lace to Toe Sneaker | COMFORTECH

14427



100



001



111



229



410

100 White | 001 Black | 111 Black & White | 229 Cognac Smooth | 410 Navy

Smooth leather upper, breathable mesh linings for additional comfort, fully cushioned Comfortech footbed with sheepskin leather cover and molded EVA for all-day comfort, durable EVA outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 8-11, 12, 13

Social Plain Toe Slip On Sneaker | COMFORTECH

14428



229



111

229 Cognac Smooth | 111 Black & White

Smooth leather upper, breathable mesh linings for additional comfort, fully cushioned Comfortech footbed with sheepskin leather cover and molded EVA for all-day comfort, durable EVA outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 8-11, 12, 13

Crossover Lace to Toe Sneaker | COMFORTECH

14307



051



001



100



221



410

051 Mushroom Crazy Horse | 001 Black | 100 White | 221 Cognac | 410 Navy

Soft leather upper, breathable mesh linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Crossover Moc Toe Elastic Lace Boat Shoe | COMFORTECH 14426



416



051



246

416 Navy Nubuck | 051 Mushroom Nubuck | 246 Brown Nubuck

Milled nubuck with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Crossover Moc Toe Slip On | COMFORTECH

14421



051



416

051 Mushroom Nubuck | 416 Navy Nubuck

Milled nubuck with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15

Trail Mix Plain Toe Chukka Boot | COMFORTECH

14424



216



010



216

216 Mocha Nubuck | 010 Black Crazy Horse | 215 Brown Crazy Horse

Casual leather or nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA for long-term wearability, shock absorbing EVA midsole for utmost comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

DRESS



RUCCI
Cap Toe Double Monk Strap



001

Rucci Wingtip Lace Up Boot

13417



221

001 Black | 221 Cognac

Smooth leather with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Rucci Plain Toe Chukka Boot

13392



200



001



221

200 Brown | 001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Rucci Plain Toe Gore Boot

13403



001



221

001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



215

Rucci Cap Toe Bal Oxford

13415



005



221

215 Brown Crazy Horse | 005 Black Smooth | 221 Cognac

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



221

Rucci Wingtip Oxford

13383



001

221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction and comfort.

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15



001

Rucci Moc Toe Slip On

13386



221

001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction and comfort.

(001) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15

(221) M 7-12, 13, 14, 15 W 7-11, 12, 13



601

Rucci Moc Toe Penny Loafer

13409



001



216



221



415

601 Burngundy | 001 Black | 216 Mocha Suede | 221 Cognac | 415 Navy Suede

Smooth leather or suede upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



001

Rucci Cap Toe Oxford

13384



005



200



221

001 Black | 005 Black Smooth | 200 Brown | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

(001, 221) M 7-12, 13, 14, 15, 16, 17, 18 W 7-11, 12, 13, 14, 15

(005) M 7-12, 13, 14, 15 W 7-11, 12, 13

(200) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14



221

Rucci Cap Toe Double Monk Strap

13416



005

221 Cognac | 005 Black Smooth

Smooth leather or crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



221

Rucci Moc Toe Tassel Loafer

13402



001

221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



221

Rucci Plain Toe Oxford

13385



001

221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Rucci Weave Cap Toe Oxford

13407



221



001

221 Cognac | 001 Black

Smooth leather with weave print leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Rucci Weave Moc Toe Penny Loafer

13408



221



001

221 Cognac | 001 Black

Smooth leather with weave print leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Zaffiro Moc Toe Bit Loafer

15209



001



221

001 Black | 221 Cognac

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Zaffiro Cap Toe Oxford

15204



001



221

001 Black | 221 Cognac

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Zaffiro Moc Toe Oxford

15205



221



001

221 Cognac | 001 Black

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Zaffiro Moc Toe Venetian Loafer

15207



001



221

001 Black | 221 Cognac

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Zaffiro Moc Toe Penny Loafer

15206



221



001

221 Cognac | 001 Black

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Sorrento Cap Toe Oxford

14292



001



221

001 Black | 221 Cognac

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber sole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Sorrento Wingtip Oxford

14291



221



001

221 Cognac | 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber sole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Sorrento Plain Toe Single Monk Strap

14293



001



221

001 Black | 221 Cognac

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber sole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Sorrento Moc Toe Penny Loafer

14294



221



001

221 Cognac | 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber sole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Conetta Moc Toe Venetian

12199



221



001

221 Cognac | 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

Conetta Bike Toe Oxford

12201



001

001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

Conetta Bike Toe Slip On

12202



001

001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

Conetta Moc Toe Bit Slip On

12203



001

001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

Conetta Cap Toe Oxford

12197



001



221

001 Black | 221 Cognac

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

Conetta Wingtip Oxford

12198



221



001

221 Cognac | 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

Flex Cap Toe Oxford

14317



001

001 Black

Smooth leather upper, comfortable herringbone textile linings, fully cushioned footbed with Rebound EVA for all-day comfort and cushioning, durable rubber sole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14

Flex Plain Toe Oxford

14318



001

001 Black

Smooth leather upper, comfortable herringbone textile linings, fully cushioned footbed with Rebound EVA for all-day comfort and cushioning, durable rubber sole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Postino Cap Toe Bal Oxford

15175



001



221

001 Black | 221 Cognac

Scratch print leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14

Postino Cap Toe Oxford

15149



221



001



005

221 Cognac Perf | 001 Black Perf | 005 Black Smooth

Smooth or perf print leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

(001, 221) D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15

(005) D 7-12, 13, 14 3E 7-11, 12, 13

Postino Plain Toe Oxford

15150



001



005



221

001 Black Perf | 005 Black Smooth | 221 Cognac Perf

Smooth or perf print leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

(001, 221) D 7-12, 13, 14

(005) D 7-12, 13, 14 3E 7-11, 12, 13

Postino Bike Toe Oxford

15154



005

005 Black Smooth

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14 3E 7-11, 12, 13

Postino Bike Toe Slip On

15156



005

005 Black Smooth

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14 3E 7-11, 12, 13

Corbetta Cap Toe Oxford

14180



221



001

221 Cognac | 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with a leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15

Midtown Plain Toe Oxford | COMFORTECH

12135



001



221

001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

Midtown Moc Toe Oxford | COMFORTECH

12136



001

001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

Midtown Wingtip Oxford | COMFORTECH

12139



221



001

221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

Midtown Cap Toe Oxford | COMFORTECH

12138



221



001



200

221 Cognac | 001 Black | 200 Brown

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

(001, 221) B 9-11, 12, 13, 14 D 6-12, 13, 14, 15, 16, 17, 18 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13
(200) D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15

Midtown Moc Toe Slip On | COMFORTECH

12137



001



221

001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

(001) B 9-11, 12, 13, 14 D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

(221) D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

Midtown Bike Toe Slip On | COMFORTECH

12166



001

001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13, 14

Midtown Penny Slip On | COMFORTECH

12159



221



001

221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

Midtown Plain Toe Zip Boot | COMFORTECH

12140



001



200



221

001 Black | 200 Brown | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

(001, 200) D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15

(221) D 7-12, 13, 14 3E 7-11, 12, 13



001

001 Black

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with OrthoLite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

Forecast Bike Toe Slip On | COMFORTECH



001

001 Black

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with OrthoLite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

Forecast Bike Toe Oxford | COMFORTECH



001



221

001 Black | 221 Cognac

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with OrthoLite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

Forecast Cap Toe Oxford | COMFORTECH

12191



001



221

001 Black | 221 Cognac

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with OrthoLite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

Forecast Plain Toe Oxford | COMFORTECH

12190



001



221

001 Black | 221 Cognac

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with OrthoLite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

Amelio Moc Toe Penny Loafer | COMFORTECH

14246



001

001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned, removable footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Bologna construction for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Tux Cap Toe Oxford

14213



004

004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with leather cover for all-day comfort, durable non-leather outsole.

D 7-12, 13, 14 3E 7-11, 12, 13, 14

Tux Plain Toe Oxford

14212



004

004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with leather cover for all-day comfort, durable non-leather outsole.

D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15

Postino Plain Toe Slip On

15178



004

004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Postino Plain Toe Venetian Slip On

15208



001

001 Black

Striped velvet textile upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14

CLASSICS



KENMOOR
Wingtip Oxford

Lexington Cap Toe Oxford

17067



01

01 Black

Smooth leather upper, synthetic linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

D 7-12, 13, 14, 15 3E 7-12, 13

Lexington Wingtip Oxford

17066



01



05

01 Black | 05 Burgundy

Smooth leather upper, synthetic linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

(01) D 7-12, 13, 14, 15 3E 7-12, 13

(05) D 7-12, 13, 14 3E 7-12, 13

Lexington Wingtip Tassel Slip On

17073



01

01 Black

Smooth leather upper, synthetic linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

D 7-12, 13, 14 3E 7-11, 12, 13

Lexington Plain Toe Oxford

17079



01

01 Black

Smooth leather upper, synthetic linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

D 7-12, 13 3E 7-12



01

01 Black

Smooth leather upper, leather linings for added breathability, fully cushioned Comfortech footbed for long-term wearability, durable rubber outsole.

M 7-12, 13, 14 W 7-12, 13

Como Moc Toe Strap Loafer



01



18

01 Black | 18 Dark Cherry

Kidskin leather upper, leather linings for added breathability, durable leather sole, genuine handsewn construction.

(01) B 9-12, 13, 14 D 5-12, 13, 14, 15 3E 6-12, 13, 14

(18) D 5-12, 13, 14 3E 6-12, 13

Berkley Flex Penny Loafer



963



005



215



229



601

963 Black/Brown | 005 Black Smooth | 215 Brown Crazy Horse | 229 Cognac Multi | 601 Burgundy

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with sheepskin leather cover for all-day comfort and flexibility, durable and cushioned EVA sole with rubber heel and Flexsole Technology for out-of-the-box comfort, genuine handsewn construction.

B 9-12, 13 D 7-12, 13, 14 3E 7-12, 13, 14

Berkley Moc Toe Penny Loafer



01



05

01 Black | 05 Burgundy

Smooth leather upper, unlined shoe, cushioned heel for extra comfort, durable leather outsole, genuine handsewn construction.

B 9-12, 13, 14, 15, 16 D 6-12, 13, 14, 15, 16 E 7-11, 12 3E 6-12, 13, 14, 15, 16

Riva Moc Toe Bit Loafer | COMFORTECH

17088



01



02

05

01 Black | 02 Brown | 05 Burgundy

Kidskin leather upper, leather linings for added breathability, elastic gore under the tongue for added comfort, fully cushioned Comfortech footbed for long-term wearability, lightweight and durable polyurethane outsole.

(01, 05) B 9-12, 13, 14, 15 D 6-12, 13, 14, 15 E 6-12, 13 3E 6-12, 13, 14, 15 5E 6-12, 13, 14
(02, 03) D 6-12, 13 3E 6-12, 13, 14, 15

Pisa Moc Toe Tassel Loafer

18469



01

03

01 Black | 03 Cognac

Nappa leather and crocodile print leather upper, leather linings for added breathability, fully cushioned footbed for all-day comfort, durable non-leather outsole, genuine handsewn construction.

D 7-12, 13, 14, 15, 16 3E 7-12, 13, 14, 15, 16

Como Moc Toe Strap Loafer

17116



01

01 Black

Nappa leather upper, leather linings for added breathability, elastic gore under the tongue for added comfort, fully cushioned heel for extra comfort, buffed leather outsole.

D 5 1/2-12, 13, 14, 15 3E 6-12, 13, 14



03

Duke Bike Toe Zip Boot

17087



01

03 Antique Gold | 01 Black

Kidskin leather upper, leather linings from the toe up through the shaft for added breathability, cushioned heel for extra comfort, durable leather outsole.

(01) D 6-12, 13 E 8-11 3E 6-12, 13

(03) D 6-12, 13 3E 6.5-12, 13



18

Essex Moc Toe Zip Boot

17074



01

18 Dark Cherry | 01 Black

Kidskin leather upper, leather linings from the toe up through the shaft for added breathability, cushioned heel for extra comfort, durable leather outsole.

D 6-12, 13 3E 6-11, 12, 13



01

Kenmoor Wingtip Oxford

17109



05

01 Black | 05 Wine

Smooth calfskin leather upper, leather linings for added breathability, cushioned heel for extra comfort, classic genuine double leather outsole, Goodyear welt construction allows this shoe to be professionally resoled.

D 6-12, 13, 14 3E 6-12, 13

SEASONAL



MOTOR
Moc Toe Penny Driver

Lakeside Canvas Moc Toe Slip On

13401



410



001



020

410 Navy | 001 Black | 020 Gray

Canvas with nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned EVA footbed for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13 XW 8-11, 12, 13

Lakeside Moc Toe Slip On

13158



200



275

200 Brown Nubuck | 275 Stone Crazy Horse

Nubuck with milled leather or crazy horse with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for all day-comfort, durable rubber outsole offers durability, traction, and comfort.

(200) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15 XW 7-11, 12, 13

(275) M 7-12, 13, 14 W 7-11, 12, 13 XW 7-11, 12, 13

Lakeside Moc Toe Oxford

13157



200



275

200 Brown | 275 Stone

Nubuck with milled leather or crazy horse with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for all day-comfort, durable rubber outsole offers durability, traction, and comfort.

(275) M 7-12, 13, 14 W 7-11, 12, 13, 14 XW 7-11, 12, 13

(200) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15 XW 7-11, 12, 13

Motor Moc Toe Penny Driver | COMFORTECH

13411



221



001

200

221 Cognac | 001 Black | 200 Brown

Weave print leather with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Motor Moc Toe Bit Driver | COMFORTECH

13410



245



001



200



221

245 Brown Suede | 001 Black Smooth | 200 Brown Smooth | 221 Cognac Smooth

Smooth leather or suede with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Motor Moc Toe Venetian Driver | COMFORTECH

13412



215



001



221



414

215 Brown Crazy Horse | 001 Black Smooth | 221 Cognac Smooth | 414 Navy Suede

Smooth leather, casual leather or suede with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and an anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

Cozy Moc Toe Tie Slipper | COMFORTECH

12184



269



061



202

269 Sand | 061 Gray Suede | 202 Chocolate

Suede upper, soft, faux shearling linings for added warmth, fully cushioned, removable Comfortech footbed with OrthoLite® high rebound foam, durable indoor/outdoor rubber outsole.

M 8-13 (Whole sizes only) W 8-13 (Whole sizes only)

LICENSEES

Florsheim Belt Licensee | Status Men's Accessories | 800.837.8686 | www.florsheimaccessories.com

Florsheim Occupational Footwear Licensee | Warson Group, Inc. | 877.753.2426 | www.warson-group.com

Florsheim Shoe Care Licensee | Rochester Shoe Tree | 866.627.3800 | www.rochestershootree.com

SALES

Mallory Bernstein

mallory.bernstein@florsheim.com | 651.894.4511 | Senior Strategic Account Manager

Cindy Brown

cindy.brown@florsheim.com | 262.893.0600 | Senior Strategic Account Manager

Tom Herrmann

tom.herrmann@florsheim.com | 352.250.9520 | LA, MS, FL, AL, GA, NC, SC

Gonzalo Peña

gpena@weycogroup.com | Work: +1.786.604.6862 Cell: +1.954.684.1910 | International Sales

Carla Piedrahita

carlap@weycogroup.com | Work: +1.786.604.6862 Cell: +1.786.252.0699 | International Sales

Bill Pettit

bpettit@shaw.ca | 604.803.2024 | Canada - British Columbia

Stephane Pinoul

spinoul@stepsagency.ca | 514.240.5166 | Canada - Quebec

Ali Randall

ali.randall@florsheim.com | 952.215.6028 | Strategic Account Manager

Josh Rogowsky

josh.rogowsky@florsheim.com | 908.403.3627 | NJ, CT, RI, MA, NH, VT, ME, NY, PA, MD, DE, VA, WV, Ontario

Mark Sullivan

mark.sullivan@florsheim.com | 773.858.6480 | IL, ND, SD, MN, WI, MT, WY, CO, IA, NE, KS, AK, MO, IN, OH, MI

Bruce Wachholtz

bruce.wachholtz@florsheim.com | 714.349.7770 | AZ, CA, ID, NM, NV, OR, UT, WA

Josh Wisenthal

jwisenthal@weycogroup.com | 514.224.8632 | Canada - Majors

Ed Wohead

ed.wohead@florsheim.com | 214.578.2205 | Strategic Account Manager, TX, OK, AR, KY, TN

STYLE	NAME	PAGE	5 - 5½	6 - 6½	15	16	17	18	B	N	E	5E	XW
12135	Midtown Plain Ox	23			X							X	
12137	Midtown Moc Slip	24			X				X			X	
12138	Midtown Cap Ox	23		X	X	X	X	X	X			X	
12140	Midtown Zip Boot	24			X	X							
12195	Berkley Flex Penny Loafer	30							X				
13157	Lakeside Moc Ox	34			X								X
13158	Lakeside Moc Slip	34			X								X
13368	Norwalk Cap Toe Ox	6			X								
13369	Norwalk Plain Toe Ox	6			X								
13383	Rucci Wingtip Ox	14			X								
13384	Rucci Cap Toe Ox	15			X	X	X	X					
13386	Rucci Moc Toe Slip On	14			X								
13401	Lakeside Canvas Moc Toe Slip On	34											X
14180	Corbetta Cap Ox	22			X	X							
14421	Crossover Moc Toe Slip On	11			X								
14272	Highland Plain Toe Oxford	8											
15149	Postino Cap Toe Oxford	21			X	X							
15156	Postino Bike Toe Slip On	22		X									
17058	Berkley Penny Loafer	30		X	X	X			X		X		
17066	Lexington Wingtip Ox	29			X								
17067	Lexington Cap Toe Ox	29			X								
17074	Essex Boot	32		X									
17087	Duke Boot	32		X							X		
17088	Riva Moc Slip	31		X	X				X		X	X	
17089	Como Moc Slip	30	X	X	X				X				
17109	Kenmoor Wingtip Ox	32		X									
17116	Como Imperial Moc Slip	31	X	X	X								
18469	Pisa Moc Slip	31			X	X							

INDEX

11768 - Dash Wingtip Oxford.....	9	14318 - Flex Plain Toe Oxford.....	20
11783 - Dash Pain Toe Oxford.....	9	14352 - Heist Lace to Toe Sneaker.....	10
12135 - Midtown Plain Toe Oxford.....	23	14354 - Heist Knit Lace to Toe Sneaker.....	10
12136 - Midtown Moc Toe Oxford.....	23	14417 - Vibe Wingtip Oxford.....	7
12137 - Midtown Moc Toe Slip On.....	24	14418 - Vibe Plain Toe Oxford.....	7
12138 - Midtown Cap Toe Oxford.....	23	14419 - Vibe Canvas Plain Toe Oxford.....	8
12139 - Midtown Wingtip Oxford.....	23	14420 - Vibe Knit Plain Toe Oxford.....	7
12140 - Midtown Plain Toe Zip Boot.....	24	14421 - Crossover Moc Toe Slip On.....	11
12159 - Midtown Penny Slip On.....	24	14422 - Satellite Knit Elastic Lace Slip On Sneaker..	9
12166 - Midtown Bike Toe Slip On.....	24	14423 - Satellite Perf Lace Up Sneaker.....	9
12184 - Cozy Moc Toe Tie Slipper.....	35	14424 - Trail Mix Plain Toe Chukka Boot.....	11
12188 - Forecast Bike Toe Oxford.....	25	14426 - Crossover Moc Toe Elastic Lace Boat Shoe	11
12189 - Forecast Bike Toe Slip On.....	25	14427 - Social Lace to Toe Sneaker.....	10
12190 - Forecast Plain Toe Oxford.....	26	14428 - Social Plain Toe Slip On Sneaker.....	10
12191 - Forecast Cap Toe Oxford.....	26	14430 - Forge Plain Toe Chukka Boot.....	4
12195 - Berkley Flex Penny Loafer.....	30	14431 - Forge Plain Toe Gore Boot.....	4
12196 - Forecast Plain Toe Slip On.....	25	14432 - Forge Plain Toe Lace Up Boot.....	4
12197 - Conetta Cap Toe Oxford.....	20	14433 - Vibe Plain Toe Chukka Boot.....	7
12198 - Conetta Wingtip Oxford.....	20	15149 - Postino Cap Toe Oxford.....	21
12199 - Conetta Moc Toe Venetian.....	19	15150 - Postino Plain Toe Oxford.....	21
12201 - Conetta Bike Toe Oxford.....	19	15154 - Postino Bike Toe Oxford.....	22
12202 - Conetta Bike Toe Slip On.....	19	15156 - Postino Bike Toe Slip On.....	22
12203 - Conetta Moc Toe Bit Slip On.....	19	15175 - Postino Cap Toe Bal Oxford.....	21
13157 - Lakeside Moc Toe Oxford.....	34	15178 - Postino Plain Toe Slip On.....	27
13158 - Lakeside Moc Toe Slip On.....	34	15198 - Renegade Wingtip Oxford.....	2
13368 - Norwalk Cap Toe Oxford.....	6	15199 - Renegade Plain Toe Chukka Boot.....	2
13369 - Norwalk Plain Toe Oxford.....	6	15201 - Renegade Plain Toe Gore Boot.....	2
13370 - Norwalk Plain Toe Chukka Boot.....	5	15202 - Renegade Wingtip Lace Up Boot.....	1
13376 - Norwalk Plain Toe Lace Up Boot.....	5	15204 - Zaffiro Cap Toe Oxford.....	17
13383 - Rucci Wingtip Oxford.....	14	15205 - Zaffiro Moc Toe Oxford.....	17
13384 - Rucci Cap Toe Oxford.....	15	15206 - Zaffiro Moc Toe Penny Loafer.....	17
13385 - Rucci Plain Toe Oxford.....	15	15207 - Zaffiro Moc Toe Venetian Loafer.....	17
13386 - Rucci Moc Toe Slip-on.....	14	15208 - Postino Plain Toe Venetian Slip On.....	27
13392 - Rucci Plain Toe Chukka Boot.....	13	15209 - Zaffiro Moc Toe Bit Loafer.....	16
13393 - Norwalk Side Zip Boot.....	5	15210 - Renegade Plain Toe Oxford.....	2
13401 - Lakeside Canvas Moc Toe Slip On.....	34	15211 - Renegade Cap Toe Lace Up Boot.....	1
13402 - Rucci Moc Toe Tassel Loafer.....	15	15212 - Renegade Plain 4-Eye Boot.....	1
13403 - Rucci Plain Toe Gore Boot.....	13	17057 - Dailey Cap Toe Oxford.....	30
13404 - Norwalk Moc Toe Slip On.....	5	17058 - Berkley Moc Toe Penny Loafer.....	30
13407 - Rucci Weave Cap Toe Oxford.....	16	17066 - Lexington Wingtip Oxford.....	29
13408 - Rucci Weave Moc Toe Penny Loafer.....	16	17067 - Lexington Cap Toe Oxford.....	29
13409 - Rucci Moc Toe Penny Loafer.....	14	17073 - Lexington Wingtip Tassel Slip On.....	29
13410 - Motor Moc Toe Penny Driver.....	35	17074 - Essex Moc Toe Zip Boot.....	32
13411 - Motor Moc Toe Bit Driver.....	35	17079 - Lexington Plain Toe Oxford.....	29
13412 - Motor Moc Toe Venetian Driver.....	35	17087 - Duke Bike Toe Zip Boot.....	32
13414 - Norwalk Wingtip Oxford.....	6	17088 - Riva Moc Toe Bit Loafer.....	31
13415 - Rucci Cap Toe Balmoral Oxford.....	14	17089 - Como Moc Toe Strap Loafer.....	30
13416 - Rucci Cap Toe Double Monk Strap.....	15	17109 - Kenmoor Wingtip Oxford.....	32
13417 - Rucci Wingtip Lace Up Boot.....	13	17116 - Como Moc Toe Strap Loafer.....	31
14180 - Corbetta Cap Toe Oxford.....	22	18469 - Pisa Moc Toe Tassel Loafer.....	31
14212 - Tux Plain Toe Oxford.....	27		
14213 - Tux Cap Toe Oxford.....	27		
14246 - Amelio Moc Toe Penny Loafer.....	26		
14272 - Highland Plain Toe Oxford.....	8		
14273 - Highland Canvas Plain Toe Oxford.....	8		
14284 - Lodge Plain Toe Chukka Boot.....	3		
14285 - Lodge Plain Toe Gore Boot.....	3		
14286 - Lodge Cap Toe Lace Up Boot.....	3		
14291 - Sorrento Wingtip Oxford.....	18		
14292 - Sorrento Cap Toe Oxford.....	18		
14293 - Sorrento Plain Toe Single Monk Strap.....	18		
14294 - Sorrento Moc Toe Penny Loafer.....	18		
14307 - Crossover Lace to Toe Sneaker.....	11		
14317 - Flex Cap Toe Oxford.....	20		



UNITED STATES
333 W ESTABROOK BLVD.
GLENDALE, WI 53212
1.866.454.0449

CANADA
8205 MONTREAL TORONTO BLVD.
MONTREAL-WEST, QUEBEC
1.800.363.5762