



SPACER INSERTION INSTRUCTIONS LOD 157

If less recline is desired, spacers can be inserted using the long screws to reattach to the base. First, remove all four (4) screws to detach the base from the chair. Insert spacers *in the rearward holes* and reattach the base to the bottom of the chair.

