



DATE: Feb 26, 2016
 SKU NUMBER: DRK32-FF1A
 SKU NAME: B'S DOUBLE STROLLER
 AGILE NUMBER: 1100940344_Instruction
 LANGUAGE CODE: 3LAG1 (ENGLISH / LAAM SPANISH / CANADIAN FRENCH)
 TYPE OF APPLICATION: Printing
 NOTES:
 SIZE: 9" X 4.5" folded to 4.5" X 4.5"
 MATERIAL: 128gsm BSC
 COLOR: 1C + 1C (Blk)
 COATING: 2/S Waterbase



© 2016 American Girl. All rights reserved. Todos los derechos reservados. Tous droits réservés. All American Girl marks are trademarks of American Girl. Marcas registradas utilizadas bajo licencia. American Girl ainsi que les marques et designs y afférents appartiennent à American Girl. **MADE IN CHINA. HECHO EN CHINA. FABRIQUÉ EN CHINE.** Retain this address for future reference: American Girl, 8400 Fairway Place, Middleton, WI 53562, U.S.A. **Importado y distribuido por** A.G. México Retail, S. de R.L. de C.V., Miguel de Cervantes Saavedra No. 193, Pisos 10 y 11, Col. Granada, Delegación Miguel Hidalgo, C.P. 11520, México, D.F. Conserver ces informations pour s'y référer en cas de besoin. American Girl Canada, 8400 Fairway Place, Middleton, WI 53562, U.S.A. **Manufactured for and imported into the EU by:** Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

americangirl.com/service

DRK32G1
1100940344



Bitty's Double Stroller Carriola doble de Bitty Poussette double de Bitty

Component	Componente	Contenu
1 stroller	1 carriola	1 poussette

**Adult assembly is required.
 Requiere montaje por un adulto.
 Doit être assemblé par un adulte.**

CAUTION : For adult assembly only. It is intended to be used with Bitty Baby® or Bitty Twins® dolls. Do not use to transport children.


PRECAUCIÓN: para montaje por un adulto. Este producto es un juguete diseñado para usarse con las muñecas Bitty Baby o Bitty Twins. No usar para transportar niños.

MISE EN GARDE : Doit être assemblé par un adulte seulement. Ce produit est un jouet. Il a été conçu pour être utilisé avec les poupées Bitty Baby ou Bitty Twins. Ne pas s'en servir pour transporter des enfants.




Opening the Stroller • Abrir el cochecito • Pour ouvrir la poussette

1. Pull up on the handle and unfold the stroller.
 Pull up on the handle and unfold the stroller.
 Pull up on the handle and unfold the stroller.



2. Guide the locks together on each side of the stroller. It may be necessary to push the lever over the button to secure it.
 Guide the locks together on each side of the stroller. It may be necessary to push the lever over the button to secure it.
 Guide the locks together on each side of the stroller. It may be necessary to push the lever over the button to secure it.



Assembling the wheels • Montar las ruedas • Pour assembler les roues



Collapsing the Stroller • Doblar el cochecito • Pour replier la poussette

1. Press the release button on the frame locks and pull up the levers on each side of the stroller.
 Press the release button on the frame locks and pull up the levers on each side of the stroller.
 Press the release button on the frame locks and pull up the levers on each side of the stroller.
2. Allow the stroller to fold down slowly into the collapsed position.
 El cochecito se plegará lentamente a la posición doblada.
 Laisser la poussette se replier lentement.

