



GENERAL MEASUREMENTS AND INFORMATION

Please note:

The Main Curtain, Teaser House PA, and various other soft goods are always hanging in the theatre. Some items are there for the use by traveling productions. If soft goods and/or House PA need to be removed prior to a show's load-in, this will constitute a work call and will be charged as an additional cost to the promoter.

STAGE	MEASUREMENT
PROSCENIUM WIDTH / OPENING	79'11"
PROSCENIUM HEIGHT Deck to the bottom of Lambrequin frame	31'0"
Deck to the bottom of arch plaster	35'8"
FRONT EDGE OF STAGE TO US EDGE OF FIRE CURTAIN (0'0")	4'3"
DEPTH OF SMOKE POCKET	13"
FIRE CURTAIN (0'00") TO BACK WALL	34'7"
STAGE FLOOR TO BOTTOM OF PICTURE SHEET	35'9"
GRID HEIGHT (stage to the bottom of steel)	75'0"
AVERAGE BATTEN LENGTH (Battens have bridals)	75'0" (Line sets #1, #2, #3 are 95'0")
PIPE TRAVEL DISTANCE	66'4"
MAXIUM ARBOR CAPACITY	900 lbs.
TOTAL COUNTERWEIGHT AVAILABLE FOR SINGLE PURCHASE (LS#1-64)	19,000 lbs. Each brick- 25 lbs.
TOTAL COUNTERWEIGHT AVAILABLE FOR DOUBLE PURCHASE (LS#65-74)	18,000 lbs. Each brick - 17 lbs. 13' arbors capacity of 900 lbs. (+/-)
OUT TRIM OF THE CENTER CLUSTER	Stage to the bottom cluster- 37'6"



GENERAL MEASUREMENTS AND INFORMATION

HOUSE	MEASUREMENT
FRONT EDGE OF STAGE TO ROCK & ROLL MIX POSITION	77'10"
FRONT EDGE OF STAGE TO BROADWAY MIX POSITION	124'3"
FRONT EDGE OF STAGE TO REAR OF HOUSE MIX POSITION	136'
MIX POSITIONS: ROCK & ROLL (center of house Rows U-Z) BROADWAY (Rows OO-RR #51-65) OASIS REAR OF HOUSE The Oasis position is best for lighting or camera position. This location is not for use by audio	Rock & Roll: 25' (w) x 9'6" (d) Broadway: 14' (w) x 8'5" (d) Oasis: 20' (w) x 12' (d)
FRONT OF STAGE @ CENTER TO BALCONY RAIL	59'0"
HEIGHT OF BALCONY RAIL FROM STAGE LEVEL	17'0"
FRONT OF STAGE @ CENTER TO BOX BOOMS	73'8"
HEIGHT OF BOX BOOM FROM STAGE (Measurements from lowest to highest)	23'0" – 1 st Rung 25'3" – 2 nd Rung 27'6" – 3 rd Rung 29'9" – 4 th Rung
FRONT EDGE OF STAGE TO THE ORCHESTRA SEATS	First Row: 23'0" Last Row: 132'0"
SIDE SCREEN INFORMATION (The Fox does not own side screens.) Rigging Points R19 & R20 for House Left R11 & R12 for House Right	No wider than 14' Screen height 7.8' for 16:9 ratio Screen height 10.5' for 4:3 ratio Throw distance from balcony rail – 45.5'
RECOMMENDED CABLE LENGTHS / RUNS:	
SR to RR Mix Position	200'
SR to Oasis Mix Position	250'
SR to Broadway Mix Position	250'
SR to Center of Balcony Rail	200'
SL to RR Mix Position	200'
SL to Oasis Mix Position	250'
SL to Broadway Mix Position	250'
SL to Center Balcony Rail	200'
SL to Center of Pit	200'



GENERAL MEASUREMENTS AND INFORMATION

PIT	MEASUREMENTS
DEPTH OF PIT AT HOUSE LEVEL TO STAGE	3'5"
LOWEST DEPTH OF PIT FROM STAGE	11'3"
INTERNAL WIDTH OF PIT	65'9"
INTERNAL DISTANCE OF PIT FROM CENTER LINE TO THE ARCH OF THE PIT WALL	19'9"
EDGE OF STAGE TO EACH ROW OF PIT SEATING (measured from edge to front leg of chair)	Row AAA 4' 4" Row BBB 7' 1/4" Row CCC 10' 5" Row DDD 13' 7" Row EEE 16' 8"

House to Stage Access: is limited by the house PA system in front of the stairs obstructing the pathway. However, stairs can be placed in the pit (depending on seating arrangements in the pit) after being advanced with production