

Stylish design and proven reliability makes Barracuda our most popular quality banner stand. Barracuda is the most feature-rich single-sided roller banner available and has been specially designed for maximum convenience and ease of use.

#### features & benefits

- Choice of 800 or 1000mm widths
- Available in anodised silver
- Charcoal grey end caps
- Internal graphic housing designed to accommodate graphic media up to 450 microns thick\*
- Ratchet tensioner
- Twist & lock telescopic pole
- Supplied with quality foam padded carry bag
  - \*Please test your substrate suitability before use






Universal grippa/ self-adhesive top rail



Ratchet Tensioner\*



Integral Pole Storage



Telescopic Pole (Twist & Lock)

\*Graphic tension may be re-applied or added to by turning the ratchet tensioner clockwise; 6 clicks of the ratchet tensioner equal 1 revolution of the banner stand spring. (NB Units are supplied pre-tensioned)

# hardware specifications

Hardware Dimensions (mm):

2210 max (h) x 855 (w) x 195 (d) approx. 87.00" (h) x 33.66" (w) x 7.68" (d) approx.

Base Dimensions (mm):

80 (h) x 855 (w) x 195 (d) approx. 3.15" (h) x 33.66" (w) x 7.68" (d) approx.

4.5kg (9.92lbs) approx (including carry bag)

# graphic specifications

Visible Graphic Dimensions (mm): 2130 max (h) x 800 or 1000 (w) 83.85" max (h) x 31.50" or 39.37" (w) 750 min (h) x 800 or 1000 (w) 29.53" min (h) x 31.50" or 39.37" (w) Substrate: Add 200mm to base of graphic to allow for roller mechanism Reccomended material thickness

225 - 450 microns (8.86 - 17.72 Mils)

#### additional into

Included in kit:

Base, top rail, telescopic pole and carry bag




# **Assembly Instructions**

### Banner stand assembly



Turn the base over and open pole retainers. the Remove the pole from the base. Important: Close the pole retainers before using the banner stand.



Set the telescopic pole to the desired graphic height. Twist clockwise to lock, anticlockwise to unlock. Fit the pole into the base.

Lift the top rail to raise the graphic from the base. Lean the banner stand backwards and continue to extend the graphic.




Secure the graphic position by locating top rail onto the pole.

Important: Hold the top rail whilst lowering the banner to prevent damage to the graphic. (do not drop)

## Graphic attachment - Adhesive rail option



Rotate the rail end cap to expose the plastic adhesive rail insert.



Slide the rail insert from the top rail. Adhere the insert to the front of the graphic.




Slide the rail insert and graphic into the top rail. Close the rail end cap.

# Graphic attachment - Grippa rail option (ideal for textiles and PVC)



Using the Allen key stored in the base, loosen the top rail screws. Rotate the rail end cap to expose the steel flat bar.



Slide the flat bar from the top rail and remove the backing paper.



the flat bar to the back of the Slide the flat bar and graphic into the top rail. Tighten the screws to secure the top rail. Close the rail end cap.

#### Graphic attachment - Base



Align and adhere hook fastener squarely to the bottom shorter edge of the graphic. (attach to back of graphic)



Securely attach the graphic to the loop fastener on the banner leader strip.



Whilst holding the graphic, remove the locking pin from the base and gently allow the graphic to retract. Re-fit the moulded end cap

WARNING: Always attach graphic to base and top rail before removing the locking pin.