




### INSTALLATION GUIDE FOR WOOD OR STEEL STUD CONSTRUCTION – INTERIOR ATTACHMENT



Maximum Distance Between Framing and Washer	Required Screw Length	Corresponding Screw Size
5/8"	1 5/8"	#6
1"	2"	#6
1 1/2"	2 1/2"	#8
2"	3"	#8
2 1/2"	3 1/2"	#10
3"	4"	#10
3 1/2"	4 1/2"	#10
4 1/2"	5 1/2"	#10
5"	6"	#10



PRONGS PRE-SET INTO FOAM




CORROSION RESISTANT CERAMIC COATING


**Screw Length:** Screws should be at least 1" longer than the total thickness of interior sheathing components, i.e., face of framing to underside of washer. For example, an assembly with two layers of 1" insulation has a total thickness of 2" and requires a minimum 3" screw.

**Recommended Fastening Patterns:**

ECOMAXci® FR    ECOMAXci® FR White    TSX-8520    Thermasheath®    Durasheath®    R-Matte®    Thermasheath®-XP



4'x8' Panel – 16" o.c. studs



4'x8' Panel – 24" o.c. studs

Additional fasteners (up to 12:16 spacing) may be required in locations expected to experience additional loading (heavy wind drafts/gusts, accelerated wear and tear, etc.).

**Additional Notes:**

- Head should be flush with insulation, do not countersink
- Other materials, such as gypsum, should be fastened separately per manufacturer's instructions



**Rmax Sales Offices and Plant Locations**

**Central:**

13524 Welch Road  
Dallas, Texas 75244

Phone: 1-800-527-0890

**East:**

1649 South Batesville Road  
Greer, South Carolina 29650

Phone: 1-800-845-4455

**West:**

210 Lyon Drive  
Fernley, Nevada 89408

Phone: 1-800-762-9462